

**AIRCRAFT PARKING
CHART - ICAO
APRON U**

APRON ELEV **TBD**

TWR	121.80
GND	122.00

**EILAT / ILAN &
ASSAF RAMON (LLER)**

ELEVATIONS ARE IN FEET
DIMENSIONS ARE IN METRES
BEARINGS ARE MAGNETIC

INS COORDINATES FOR
AIRCRAFT STANDS,
SEE AD 2.7-14A


TAXIWAYS 23-45m WIDE
TAXIWAYS AND
APRON BEARING
STRENGTH PCN TBD

FIRE STATION

**NOTE: Pushback is
not permitted
without specific
ATC approval.**



VAR 4° E 2014
ANNUAL RATE
OF CHANGE 5' E



LEGEND	
TAXIWAY DESIGNATOR	B
STARTING POINT	
TAXILANE	
APRON BOUNDARY	
INTERMEDIATE HOLDING POSITION	

CHANGES: Taxilane outside of the APRON deleted

INS Coordinates for Aircraft Stands (GND East)

Stand No.	Coordinates	Stand No.	Coordinates
U1	29° 43' 28.56" N 35° 00' 27.05" E	U10	29° 43' 44.17" N 35° 00' 31.42" E
U1A	29° 43' 28.02" N 35° 00' 27.47" E	U10A	29° 43' 43.24" N 35° 00' 31.73" E
U2A	29° 43' 29.66" N 35° 00' 27.93" E	U10B	29° 43' 44.88" N 35° 00' 32.19" E
U3	29° 43' 30.99" N 35° 00' 27.73" E	U20	29° 43' 29.33" N 35° 00' 36.14" E
U3A	29° 43' 31.30" N 35° 00' 28.39" E	U21	29° 43' 32.15" N 35° 00' 36.93" E
U4	29° 43' 33.93" N 35° 00' 28.55" E	U21A	29° 43' 31.84" N 35° 00' 36.27" E
U4A	29° 43' 33.39" N 35° 00' 28.97" E	U22A	29° 43' 33.48" N 35° 00' 36.73" E
U5A	29° 43' 35.03" N 35° 00' 29.43" E	U23	29° 43' 34.58" N 35° 00' 37.61" E
U6	29° 43' 36.36" N 35° 00' 29.23" E	U23A	29° 43' 35.12" N 35° 00' 37.19" E
U6A	29° 43' 36.67" N 35° 00' 29.89" E	U24	29° 43' 37.07" N 35° 00' 38.31" E
U7	29° 43' 38.85" N 35° 00' 29.93" E	U24A	29° 43' 36.76" N 35° 00' 37.65" E
U7A	29° 43' 38.31" N 35° 00' 30.35" E	U25A	29° 43' 38.40" N 35° 00' 38.11" E
U8A	29° 43' 39.95" N 35° 00' 30.81" E	U26	29° 43' 39.50" N 35° 00' 38.99" E
U9	29° 43' 41.28" N 35° 00' 30.61" E	U26A	29° 43' 40.04" N 35° 00' 38.57" E
U9A	29° 43' 41.59" N 35° 00' 31.27" E		